
# Topic 6

#### 6. Generation of Bit-error

- 6.1 Introduction
- 6.2 Receiver
- 6.3 Mechanisms for error generation
- 6.4 Bit Error Rate
- 6.5 Eye diagram
- 6.6 Power Penalties

# **Introduction (i)**



- An optical communication contains receiver and transmitter:
- Transmitter: optical source (LD or LED), modulator, Drive

electronics (convert electronic signals to optical signals)


• Receiver: photodetector, Amplifier and Regenerator (convert

optical signals to electrical signals for data-out, or

amplify for further process)

2

### Block diagram of a digital fibre system




#### **Generation of errors:**

- Conversion from electric signals to optical signal: noise from detector
- Regeneration of optical signals: a decision circuit used during each bit period and compare to some pre-set threshold

Amplitude > threshold, "1" is regenerated Amplitude < threshold, "0" is regenerated

However, internal or external disturbance ⇒ errors

# **Mechanisms for Error Generation**



#### Insufficient signal-to-noise ratio:

When a "0" received, the voltage may be momentarily above the threshold  $\Rightarrow$  "0" becomes "1"


#### Timing variation

It causes the waveform to be sampled at other than its maximum amplitude

### Intersymbol interference due to dispersion

Some of the energy belongs to one particular bit period actually in one of the adjacent bit periods

# **Bit-Error-Rate**



Bit error: registered as a "1" when "0" was sent, or a "0" when a "1" was sent

$$BER = N_e/N_t = N_e/Bt$$

N<sub>e</sub>: Number of errors

N<sub>t</sub>: Total Number of bits


B: Bit rate

t : time

Typical BER:  $10^{-9} \sim 10^{-12}$  ( $10^{-9}$  is a minimum requirement)

### Fluctuating Signal Generated at Receiver

Prob. measuring "0" when "1" sent Prob. of "0" sent Prob. of "1" sent BER = p(1)P(0/1) + p(0)P(1/0)BER = p(1)P(0/1) + p(1/0)



- P(0/1), P(1/0)
   Depend on probability function of sampled I
- Prob Fn (I) depends on noise sources
- •For p-i-n photodiode main noise contribution is thermal (Gaussian) noise and shot noise (~Gaussian)


# **Calculation of BER**

BER = 
$$p(1)P(0/1) + p(0)P(1/0)$$
  
BER =  $\frac{1}{2}[P(0/1) + P(1/0)]$ 

Assumption: The received signals follow Gaussian probability distribution The probability for the measured value falling in the range S to S+ds

$$p(s)ds = \frac{1}{\sqrt{2\pi}\sigma} \exp\left[-\frac{-(s-m)^2}{2\sigma^2}\right]ds$$

Where m: the mean value of signal;  $\sigma$ : standard deviation of distribution




Based on the above equation, it can be obtained the relationship between BER and S/N

$$BER = \frac{1}{2} \left[ 1 - erf\left(\frac{1}{2\sqrt{2}} \frac{S}{N}\right) \right]$$

$$erf(x) = \frac{2}{\pi} \int_0^x e^{-y^2} dy$$
Signal-to-noise ratio

- Increasing Signal-to-noise ratio ⇒ Decreasing BER
- Very important for calculating power budget



•A method indicating system performance:

**Eye diagram or pattern**: Examination of the received waveform on an oscilloscope

Display obtained over one bit duration:Superimposing all possible pulse sequences

# Eye Diagram (ii)



Reliable transmission requires an open "eye"

### **Power Penalty**

•Bit errors due to optical dispersion can be reduced by having a higher intensity signal at the receiver

This is termed as the "Dispersion Penalty" and would appear in the power budget for the system

- •The presence of power in logic level "0" gives some additional errors compared to ideal case where there is no power
- Extra receiver power is required to reduce these errors
- termed as extinction ratio penalty

### T6 Summary

- •The bit-error-rate which can be tolerated determines the power at the receiver for a given data rate.
- •Power penalties are paid for e.g. dispersion, and non-zero extinction ratios.
- Due to dispersion and loss within a fibre it is necessary along a fibre link to regenerate the signal from time-to-time.
- •A regenerator consists of a detector, electronics, and a transmitter which will resend an input signal this must be tied to a specific data type though

### **T6 Tutorial Questions**

T6.1 Consider an 800nm receiver (silicon p-i-n photodiode). Assume 20MHz bandwidth, 65% quantum efficiency, 1nA dark current, 8pF junction capacitance and a 3dB amplifier noise figure. The receiver is illuminated with 5  $\mu$ W of optical power. Determine the noise currents due to shot noise, and thermal noise. What is the signal to noise ratio?